



Compatibility Zone Legend (nonresidential)

- Zone 1 No people other than aircraft occupants, airport personnel, and other persons authorized by airport regulations.
- Zone 2 No more than 5 people per acre average over the site.
- Zone 3 No more than 25 people per acre average over the site.
- Zone 4 No more than 4 people per acre in buildings and no more than 75 people per acre outside of buildings.
- Zone 5 No more than 100 people per acre average over the site.
- Zone 6 Standard zoning restrictions.